

**DANCOVER<sup>®</sup>**

**.com**

Manual  
for  
Hydroponic Grow Tower  
with LED

# TOWER ASSEMBLY GUIDE

## TOWER COMPONENTS

---



Water Tank



Reservoir Lid



Access Port Lid



Tower (x7)



Water Level Gauge



Shower Cap & Lid



Transition Layer



Six-way



Hose



Pump



Adapter



Timer



Basket(x42)



Sponge(x42)

## Optional

---



Screw(x16)



Wheel(x4)



Support Frame



Nut(x16)

## TOWER ASSEMBLY

- ① Place the bucket on flat ground.



- ② Tie loop to prevent water from running down cord to outlet.




**DO NOT** plug in pump until assembly is complete and reservoir has been filled



- ③ Insert the water level gauge into this small round hole.



④ Stack the towers on the water tank, pass the hose through the tower center, connect with the six-way connection at the top, and cover the top cover.



⑤ Put the sponges in the baskets and place the baskets over the post hole.



⑥ Fasten the wheel with the screw nut on the support frame. Lift the bucket up onto the support frame.



⑦ Put the bucket on the support frame.



## Contact information

Austria



Belgium



Croatia



Denmark



Estonia



Finland



France



Germany



Ireland



Italy



Latvia



Lithuania



Nederland



Norway



Poland



Portugal



Spain



Sweden



Switzerland



UK

