


# Aufbau-Anleitung Jumbo Aufzuchtstation

## Assembly-Instruction Jumbo Propagator

| No.  | 1   | 2   | 3   | 4   | 5   | 6  | 7   | 8   |
|------|---|---|---|---|---|--|---|---|
|      |  |  |  |  |  |  |  |  |
| Q'ty | 6PCS  | 4PCS  | 4PCS  | 4PCS  | 4PCS  | 3PCS   | 1PCS  | 20PCS   |

