

DANCOVER[®]

.com

**Manual Part 2
Safety Advice**

Attention!

Please read these instructions and safety advice before you start to assemble your metal shed. Keep these instructions in a safe place for future reference.

Customer Service

Do you have questions in regard to your new product or do you need spare parts, please visit our shop or contact us by phone, e-mail or use our chat.

Safety Advice

When establishing a metal shed it is your responsibility to comply with local rules and regulations and to ensure that the shed is assembled correctly according to the enclosed manual. It is very important that you assemble all parts according to the instructions. Do not skip any parts or any steps.

Protective gear for assembly

Please take care when assembling the metal shed as some parts may have sharp edges. Use work gloves as recommended in the manual – and preferably shoes and safety goggles. If using a ladder or power tools, be sure to follow the manufacturer's safety advice. Keep children away from the assembly site.

Do not lean against the metal shed during construction. Do not place your metal shed in an area with excessive wind. Do not attempt to assemble this shed if you are tired, have taken drugs or alcohol.

Base for the shed

Make sure that you place the metal shed on a firm and plane surface preferably concrete, but flagstones, wood, or gravel can also work. The base must be 100% in level and with the right angles – check by measuring the two diagonal dimensions. Always fasten the structure to the base to prevent accidents in case of extreme weather. Furthermore, make sure that doors are closed in case of a storm.

Metal sheds are temporary structures

Please note that even though our metal sheds are sturdy and durable structures, they are not permanent buildings as such so it is upon you to regularly check the structure to make sure that it is safe and in working order. As the metal shed is made of lightweight materials, you must make sure that the shed at all times is safely secured and fastened to the base so the shed does not cause damage to others in case of bad weather. Be sure that you do not hit any hidden cables or pipes in the ground when inserting the ground anchors or similar.

Condensation

Please be aware that temperature changes and moisture in the air can cause dew or condensation to appear outside and inside your ProShed garden shed as it is not insulated. This is normal and does not mean your ProShed is leaking.

Insurance

Please check whether a metal shed is covered by your home contents insurance. It is your responsibility to lock the metal shed to prevent theft from the premises – all our metal sheds are lockable but in general, you have to provide the padlock.

Never stay inside the shed during extreme weather conditions. In the event of snow always remove snow from the roof as heavy snow may cause the shed to collapse. Please note that you can buy reinforcement rafters for some of our metal sheds if you live in areas with much snow.

Warranty information

Dancover warranty applies only to the normal use of the product, normal wear and tear excepted, in accordance with written use instructions or manual. If you need to clean your metal shed at some point, only use a mild detergent and lukewarm or cold water. Do not use strong agents of any kind.

Please visit dancovershop.com for information on warranty.

Please always check our website for the latest safety advice and manual.